

Accessories

Programming Adapter CSD for Motion Control Systems V2.5 Mini USB interface

Part No.: 6501.00135

	6501.00135	
Temperature range:		
– Operating temperature	- 10 + 65	°C
Dimension and Weight:		
– Dimension (L x B x H)	60 x 50 x 15	mm
– Mass	30	g

Note: All switches are in the "OFF" position in the as-delivered condition. These switches must be set accordingly depending on the application.

General information

The programming adapter is used to connect Brushless DC-Servomotors with integrated Motion Controller and a USB interface.

The different operating modes can be selected using the 6 DIP switches.

A Brushless DC-Servomotor with integrated Motion Controller can be connected to each programming adapter.

Driver installation

The driver is included in the setup package of FAULHABER Motion Manager (from version 5.2), which can be downloaded from the FAULHABER internet site www.faulhaber.com/MotionManager.

For detailed informations to install the driver please see instruction manual of programming adapter USB.


Description of DIP switch (S1) settings

1: Fault	ON OFF	Pull-up resistor with LED connected to programming adapter. Open collector
2: N.C. 3: N.C.		
4: USB	ON OFF	Operation with USB Deactivated
5: N.C.		
6: AGND	ON OFF	AGND and GND interconnected. AGND and GND disconnected (with separate ground).

Pin assignment

Pin Connection X1	Pin Connection X2
1 3. In	1 3. In
2 +24V	2 +24V
3 GND	3 GND
4 An In	4 An In
5 AGND	5 AGND
6 Fault	6 Fault
7 RS-232 RxD	7 RS-232 RxD
8 RS-232 TxD	8 RS-232 TxD
	9 n.c.
Connection X3	10 n.c.
USB	
	LED Status
Pin Connection X4/X5 1 +24V 2 GND	LED illuminates no error fault output switched
2 0.10	to GND
3 An In	LED does not illuminate
4 AGND	error
5 Fault	fault output high-impedance
6 3. In	ingn-inipedance

Dimensional drawing and connection information



Scale reduced

No.	Function
X1, X2	Motor connector
X3	USB
X4, X5	Supply connector; I/O
No.	Switch
S1	DIP-switch (6 switches)

For detailed information regarding FAULHABER accessories please refer to the instruction manuals. Edition 2020 Feb.18 © DR. FRITZ FAULHABER GMBH & CO. KG Specifications subject to change without notice.